

ATMC ONT1000V Installation Layout for Single Family FTTP Applications

New Construction: Homeowner / Contractor Installation Responsibility

- Install a **simplex outdoor**, 110V outlet, off a **dedicated NON-GFI circuit**.
- Pull all homeruns of CAT 5 and RG-6's from interior jacks, to outside, as shown below. **No daisy chain type of wiring.**
- **The Exit Point must be indicated before applying for buried power.**

Typical Layout Dimensions

*Layout may be reversed for left-side-of-meter application.

The Exit Point must be in place (or the location indicated) before applying for buried power.

**ATMC Contact: Kris Ward
Business Development Manager
910-755-1697 or 910-232-7424**

