

Installation of the Paradyne DSL Modem

Welcome to ATMC High Speed DSL. It is **HIGHLY** recommended that you **ONLY** use the **ETHERNET** cable to connect the DSL modem to your PC. **Do NOT use the USB cable (The Blue Wire).** If you do not have an Ethernet connection on the back of your computer, you may get one installed at a local computer store or ATMC technicians can come and install one into your PC for a fee.

Do NOT run the enclosed Paradyne (ZHONE) CD to do your install.

Connections:


Step 1: READ ALL INSTRUCTIONS INCLUDING THE PARAGRAPH ABOVE.

Hook up filters to **ALL** phones, satellite dish receivers, alarm systems, answering machines, caller id boxes, fax machines, and anything else in your house that plugs into a phone jack. You can obtain additional filters at ATMC. Your alarm company or ATMC can filter your alarm system, if you have one, for a small fee. See illustration for filter installation details. **The Phone line going to the DSL Modem does NOT get a filter.**

Step 2: Make sure your computer is off. Connect modem to the pc with the ethernet cable (Shown with the number 3 in the illustration) and make all wall connections e.g.: power (The number 4) and phone line (Numbers 1 and 2)

3.1 Connecting the Hardware

Shut down your PC before connecting the modem.



Notice the **OR** in step 3. **Do NOT connect the USB cable (The Blue Wire).** It will not be used in the installation.

Step 3: Turn on the pc and load windows. These instructions will work on all pcs running Windows 98 Second Edition or higher (Including Windows Vista) to program the modem. **To setup email there are different steps for Windows Vista.**

Step 4: Open Internet Explorer.



After approximately 30 seconds a screen will appear asking for the username and password. It will have default in the username already and the password will have several dots.

A screenshot of a PPP configuration window. It has two input fields. The first is labeled 'PPP Username:' and contains the text 'default'. The second is labeled 'PPP Password:' and contains several dots (.....).

Step 5: Delete default in the Username box and all of the dots in the Password box.

Step 6: Enter your email address in the username box eg: username@atmc.net

A screenshot of a PPP configuration window. The 'PPP Username:' field now contains 'username@atmc.net'. The 'PPP Password:' field still contains several dots (.....).

Step 7: Enter your password assigned by ATMC in the Password box.

Step 8: Click Save/Reboot



Step 9: Close the Internet Explorer.


Step 10: Wait for the Status light on the modem to become a solid green light.




Step 11: IF YOU ARE RUNNING WINDOWS VISTA PLEASE SKIP TO STEP 29. STEPS 11 THROUGH 28 ARE FOR WINDOWS 98, WINDOWS ME, WINDOWS 2000 AND WINDOWS XP ONLY AND WILL NOT WORK.

Place pointer on the start button on the lower left hand side of the screen and click the left mouse button. On the menu that appears you should see RUN near the bottom. Please place the pointer on RUN and click the left mouse button. A box will appear.


Type inetwiz in the box where it says Open then click OK.



Step 12: The Internet Connection Wizard will appear. Select Local Area Connection and click Next



Step 13: Make sure that nothing is checked inside this box. If there are checks you can left click on those checks and make them go away. Then click Next



Step 14: It will no ask about setting up an Internet Mail Account now. Select Yes and click next.




Step 15: Type your name in the Display Name box. Click Next.

Internet Connection Wizard

Your Name

When you send e-mail, your name will appear in the From field of the outgoing message. Type your name as you would like it to appear.

Display name: 

For example: John Smith


< Back Next > Cancel Help

Step 16: Enter your E-Mail address in the E-mail address box. Click Next.

Internet Connection Wizard

Internet E-mail Address


Your e-mail address is the address other people use to send e-mail messages to you.

E-mail address: 

For example: someone@microsoft.com


< Back Next > Cancel Help

Step 17: Leave the top box as POP3. Enter **mail.atmc.net** in the Incoming mail (POP3, IMAP or HTTP) server: box. Enter **smtpauth.atmc.net** in the Outgoing mail (SMTP) server: box. Click Next.




The screenshot shows the 'Internet Connection Wizard' dialog box, specifically the 'E-mail Server Names' step. The window title is 'Internet Connection Wizard'. The main title is 'E-mail Server Names'. Below the title bar, there is a text area that says 'My incoming mail server is a server.' Below this, there is a label 'Incoming mail (POP3, IMAP or HTTP) server:' followed by a text box containing 'mail.atmc.net'. Below that, there is a label 'An SMTP server is the server that is used for your outgoing e-mail.' followed by a label 'Outgoing mail (SMTP) server:' and a text box containing 'smtpauth.atmc.net'. At the bottom of the dialog, there are four buttons: '< Back', 'Next >', 'Cancel', and 'Help'.


Step 18: Enter your email address in the Account name box and enter the password that you received from ATMC when you signed up for your internet. Click next.




The screenshot shows the 'Internet Connection Wizard' dialog box, specifically the 'Internet Mail Logon' step. The window title is 'Internet Connection Wizard'. The main title is 'Internet Mail Logon'. Below the title bar, there is a text area that says 'Type the account name and password your Internet service provider has given you.' Below this, there is a label 'Account name:' followed by a text box containing 'myaddress@atmc.net'. Below that, there is a label 'Password:' followed by a text box containing '*****'. Below the password box, there is a checked checkbox labeled 'Remember password'. Below this, there is a text area that says 'If your Internet service provider requires you to use Secure Password Authentication (SPA) to access your mail account, select the 'Log On Using Secure Password Authentication (SPA)' check box.' Below this, there is an unchecked checkbox labeled 'Log on using Secure Password Authentication (SPA)'. At the bottom of the dialog, there are four buttons: '< Back', 'Next >', 'Cancel', and 'Help'.


Step 19: Click Finish.



Step 20: Open your Outlook Express by double clicking the  icon.




Step 21: Click on Tools.



Step 22: Click on Accounts.

Step 23: Click on the Mail Tab at the Top.




Step 24: Click on the  button.

Step 25: Click on the Servers Tab at the top.



Step 26: Put a check in My server requires authentication.



Step 27: Click on the  button.


Step 28: Click on the  button.

STEP 29: THESE INSTRUCTIONS ARE FOR WINDOWS VISTA USERS ONLY. DO NOT USE THESE INSTRUCTIONS UNLESS YOU ARE RUNNING WINDOWS VISTA. THEY WILL NOT WORK WITH WINDOWS 98, WINDOWS ME, WINDOWS 2000 OR WINDOWS XP. IF YOU ARE RUNNING WINDOWS 98, WINDOWS ME, WINDOWS 2000 OR WINDOWS XP YOU ARE FINISHED WITH YOUR INSTALLATION.



Click on the Start button in the lower left side of the screen.

Step 30: Click on Windows Mail at the top of the Start Menu.



Step 31: Windows Mail will open and ask for your name. Enter your name in the Box.

Your Name

When you send e-mail, your name will appear in the From field of the outgoing message. Type your name as you would like it to appear.

Display name:

For example: John Smith

Step 32: Click

Step 33: Enter your email address. Example username@atmc.net. Remember there should not be any capital letters.

Internet E-mail Address

Your e-mail address is the address other people use to send e-mail messages to you.

E-mail address:

For example: someone@microsoft.com

Step 34: Click

Step 35: The top box should remain POP3

Set up e-mail servers

Incoming e-mail server type:

Step 36: In the Incoming mail (POP3 or IMAP) server: box enter mail.atmc.net

Incoming mail (POP3 or IMAP) server:


Step 37: In the Outgoing e-mail server (SMTP) name: box enter smtpauth.atmc.net

Outgoing e-mail server (SMTP) name:

Step 38: Put a check in the box at the bottom that says Outgoing server requires authentication.

Outgoing server requires authentication
[Where can I find my e-mail server information?](#)

Step 39: Click



Step 40: Enter your entire email address in the E-mail username: box and your password you received from ATMC in the password box.

Internet Mail Logon

Type the account name and password your Internet service provider has given you.


E-mail username:

Password:


Remember password

NOTE: THE ENTIRE EMAIL ADDRESS MUST BE TYPED INTO THE E-MAIL USERNAME BOX.

Step 41: Click



Step 42: Click



Congratulations. You are now finished setting you your DSL. Click on your web browser to access the internet and Outlook Express is configured to check your email.

How to install the Microfilter?

To avoid noise in your telephone line, you must install a Microfilter at each phone.

Please use the following steps to install the Microfilter.

